

Feature codes

# + Ext.	Leave voice message
*1	One touch record
*2	Read voice message
*02	VoiceMail Main Menu
*3	Attended transfer
*03	Blind transfer
*4	Call Pickup
*04	Extension Pickup
*5	Intercom
*6	Call Parking
*70	Reset to defaults Note: When reset to defaults, the call forward default value will be 1) Always forward: Disable 2) Busy forward to voice mail: Enable 3) No answer forward to voice mail: Enable 4) Do not disturb: Disable
*71	Enable always forward
*071	Disable always forward
*72	Enable busy forward
*072	Disable busy forward
*73	Enable no answer forward
*073	Disable no answer forward
*74	Forward to number(*74+phone number) e.g.: *74501, it will forward the call to extension 501.
*074	Forward to Voicemail
*75	Enable do not disturb
*075	Disable do not disturb