


STEP 1 Logging into your device

Log into the GXP2160's administrative interface by using the supplied default username (**admin**) and default password (**admin**).



STEP 2 Configuring your Callcentric account

From the top menu bar, click on the **Accounts** tab, followed by **Accounts 1** and finally the **General Settings** option, as shown on the image below:



Once on the **General Settings** page, please use the settings detailed in the screen captures below. After you have finished entering these settings, click on the **Save and Apply** button to apply/save your settings:

The screenshot shows the Grandstream GXP2160 web interface. At the top, there is a navigation bar with the Grandstream logo and menu items: Status, Accounts, Settings, Network, Maintenance, and Phonebook. The 'Accounts' menu is expanded, showing a list of accounts (Account 1 to Account 6). The 'General Settings' page for Account 1 is displayed. The settings include:

- Account Active: No Yes
- Account Name: 201 (שם לתצוגה בלבד)
- SIP Server: [redacted].org.il (שרת מרכזי)
- Secondary SIP Server: [empty]
- Outbound Proxy: [empty]
- BLF Server: [empty]
- SIP User ID: [redacted].co.il (חשבון השלוחה)
- Authenticate ID: [empty]
- Authenticate Password: [masked] (סיסמא)
- Name: 201 (שם לתצוגה בלבד)
- Voice Mail UserID: *97 (גישה לתא הקולי)

At the bottom of the settings form, there are three buttons: Save, Save and Apply, and Reset.

Copyright © Grandstream Networks, Inc. 2015. All Rights Reserved.